



Installation Instructions Knee Pad

For '02-'06 Mini Cooper

PART # 101-482

MOSS MOTORS, LTD.

440 Rutherford St. P.O. Box 847 Goleta, CA 93117
1-800-667-7872 • FAX 805-692-2525 • www.mossmini.com

Tools required: 2.5" diameter aerosol can

Read and understand these instructions before installing this kit.

1. The backing of the knee pad is flat, and the area which it will adhere to is curved. For this reason you will need to shape the knee pad to follow the curve of the pillar. Use an aerosol can to bend the cardboard backing of the knee pad lengthwise. Bend the edges along the tape up with your hands. The edges should be contoured slightly more than down the center. The leather will try to maintain the original flat shape of the backing, so you will need to slightly over bend the backing in order for it to stay curved. Test fit the knee pad to the pillar and bend as necessary. Illustration 1.



Illustration 1



Illustration 1

2. Using the supplied alcohol pads, thoroughly clean the driver's side center console pillar. Illustration 2.



Illustration 2

Knee Pad Installation Instructions

3. Remove the backing from the two sided tape and install the knee pad to the pillar. Firmly press both edges of the knee pad to the pillar. Illustration3.



Enjoy your Mini Knee Pad!